Alphabetical index

Alphabetical index

٩	A/C (Air conditioning system)	170
	ABS (Anti-lock brake system)	148
	AFS (Adaptive front lighting	
	system)	123
	Adaptive front lighting system	
	(AFS)	123
	Air conditioning filter	299
	Air conditioning system (A/C)	
	Air conditioning filter	299
	Automatic air conditioning	
	system	170
	Airbags	
	Airbag operating conditions	63
	Airbag precautions for your	
	child	67
	Airbag warning light	340
	Curtain shield airbag operating	g
	conditions	64
	Curtain shield airbag	
	precautions	67
	Front passenger occupant	
	classification system	72
	General airbag precautions	67
	Locations of airbags	61
	Modification and disposal of	
	airbags	71
	Proper driving posture	59,67
	Side airbag operating	
	conditions	64
	Side airbag precautions	67
	SRS airbags	61
	Alarm	56
	Antenna	
	Anti-lock brake system (ABS)	148
	Armrest	232
	Ashtrays	225

	Audio system	
	Antenna	186
	AUX adapter	206
	CD player/changer	189
	MP3/WMA disc	195
	Optimal use	203
	Radio	
	Steering wheel audio switch	
	Automatic air conditioning	
	system	170
	Automatic headlight leveling	
	system	124
	Automatic light control system	
	Automatic transmission	
	Automatic transmission	101
	If the shift lever cannot be	
	shifted from P	367
	S mode	103
	AUX adapter	
	•	
В	BA (Brake assist)	148
	Back-up lights	
	Wattage	394
	Battery	
	Checking	279
	If the vehicle has discharged	
	battery	372
	Preparing and checking	
	before winter	161
	Bottle holders	
	Brake	
	Fluid	278
	Parking brake	108
	Brake assist (BA)	148

Care	
Exterior252	
Interior254	
Seat belts255	
Cargo capacity157	
Cargo hooks238	
CD changer189	
CD player189	
Chains161	
Child restraint system (CRS)	
Booster seats, definition77	
Booster seats, installation81	
Convertible seats, definition77	
Convertible seats, installation81	
Front passenger occupant	
classification system72	
Infant seats, definition77	
Infant seats, installation81	
Installing CRS with lower	
anchorages84	
Installing CRS with seatbelts81	
Installing CRS with top straps85	
Child safety	
Airbag precautions67	
Battery precautions281, 374	
Child restraint system77	
Child-protectors20	
How your child should wear	
the seatbelt37	
Installing child restraints80	
Moon roof precautions50	
Power window lock switch	
Power window precautions47	
Removed electronic key battery	
precautions303	
Seat belt comfort guide35	
Seat belt extender precautions 39	

	Seat belt precautions	38
	Seat heater precautions2	29, 231
	Trunk precautions	25
	Child-protectors	20
	Cigarette lighter	226
	Cleaning	
	Exterior	252
	Interior	254
	Seat belts	255
	Clock	221
	Coat hooks	236
	Compass	246
	Condenser	278
	Console box	214
	Cooling system	
	Engine overheating	
	Cornering assist sensors	142
	Cruise control	
	Cruise control	
	Dynamic radar cruise contro	
	Cup holder	
	Curtain shield airbags	
	Customizable features	406
D	Daytime running light system Defogger	123
	Rear window	
	Side mirror	178
	Dimension	380
	Dinghy towing1	66, 167
	Display	
	Dynamic radar cruise contro	
	Satellite switch mode	
	Trip information	
	Warning message	
	Do-it-yourself maintenance	263

I	Door courtesy lights	If your vehicle needs to be	
	Door courtesy lights209	towed	328
	Wattage394	If your vehicle overheats	375
	Door pockets218	Engine	
	Doors	Compartment	269
	Door glasses45	Engine switch	
	Door lock19	Hood	
	Side mirrors43	How to start the engine	98
	Driver's seat belt reminder light 341	Identification number	
	Driving	If the engine will not start	
	Correct posture59	Overheating	
	Procedures90	Engine compartment cover	
	Driving position memory28	Engine coolant	
	,	Capacity	385
	Electric power steering (EPS)148	Checking	
	Electronic key	Preparing and checking	
	If your electronic key battery	before winter	161
	is discharged369	Engine coolant temperature	
	Emergency, in case of	gauge	109
	If the engine will not start	Engine immobilizer system	
	If the shift lever cannot be	Engine oil	
	shifted from P	Capacity	384
	If the vehicle has discharged	Checking	
	battery	Preparing and checking	
	If the warning buzzer sounds339	before winter	161
	If the warning light turns on339	Engine oil maintenance data	
	If the warning message is	EPS (Electric power steering)	
	displayed	Event data recorder	
	If you have a flat tire358		
	If you lose your keys368	First-aid kit storage belt	238
	If you think something is	Floor mat	
	wrong335	Fluid	237
	If your electronic key battery	Brake	272
	is discharged369	Washer	
	_	v v a St let	ZOZ
	If your vehicle becomes stuck377		

	Fog lights			Headlight aim	318
	Switch	125		Headlight cleaner	
	Wattage	394		Headlights	
	Foot well lighting			Discharge headlights	
	Front fog lights			precautions	325
	Switch	125		Replacing light bulbs	
	Wattage	394		Switch	
	Front passenger occupant			Wattage	394
	classification system	72		Heaters	
	Front passenger's seat belt			Seat heaters	228, 230
	reminder light	341		Side mirror	178
	Front seats			Hill-start assist control	148
	Adjustment	26		Hood	266
	Driving position memory	28		Hooks	
	Seat position memory	31		Cargo	238
	Front turn signal lights			Coat	236
	Wattage	394		Shopping bag	238
	Fuel				
	Capacity	383	1	I/M test	262
	Fuel gauge	109		Identification	
	Fuel pump shut off system	336		Engine	381
	Gas station information	427		Vehicle	
	Information	395		Illuminated entry system	
	Refueling	51		Indicator lights	
	Fuel filler door	51		Initialization	
	Fuel pump shut off system	336		Items to initialize	411
	Fuses	304		Inside rear view mirror	
				Interior lights	
G	Garage door opener	241		Interior lights	209
	Gas station information	427		Switch	
	Gauges	109		Wattage	394
	Glove box	213			
	Glove box light	214	J	Jack	
				Positioning the jack	267
Н	Head restraints			Replacing the wheel	
	Adjusting	33		Jack handle	

Alphabetical index

K	Keys			Meter	
	Electronic key	2		Instrument panel light control	110
	Engine switch	98		Meters	109
	If you lose your keys	368		Mirrors	
	lf your electronic key batter	ту		Inside rear view mirror	42
	is discharged	369		Side mirror heater	178
	Key number	2		Side mirrors	43
	Keys	2		Vanity mirrors	220
	Mechanical key	2		Moon roof	48
	Wireless remote control	16		MP3 disc	195
				Multi-information display	118
L	Light bulbs				
	Replacing		0	Odometer	109
	Wattage	394		Oil	
	Lights			Engine oil	272
	Door courtesy lights			Opener	
	Fog light switch			Fuel filler door	
	Headlights switch			Hood	
	Interior light switch			Trunk	23
	Outer foot lights			Outer foot lights	
	Overhead courtesy light	209		Outer foot lights	
	Personal light switch	211		Wattage	394
	Replacing light bulbs	319		Outside rear view mirrors	
	Scuff lighting	209		Adjusting and folding	43
	Shift lever lighting	209		Driving position memory	28
	Turn signal lever	107		Outside temperature display	119
	Vanity lights	220		Overhead console	215
	Wattage	394		Overhead courtesy lights	
	Load capacity	160		Overhead courtesy lights	209
				Wattage	394
М	Maintenance			Overheating, Engine	375
	Do-it-yourself maintenance	263			
	General maintenance	259	Р	Parking assist sensors	142
	Maintenance data	380		Parking brake	108
	Maintenance requirements	257			
		105			

	Parking lights	С	hild restraint system	
	Replacing light bulbs319	i	installation	80
	Switch122	С	leaning and maintaining	1
	Wattage394	t	the seat belts	255
	PCS (Pre-collision system)154	Er	mergency Locking Retr	actor
	Personal lights		(ELR)	
	Switch211		ow to wear your seat be	
	Micro dust and pollen removal	Н	ow your child should we	ear
	mode174		the seat belt	
	Power outlet227	Pr	regnant women,	
	Power windows45	1	proper seat belt use	36
	Pre-collision system (PCS)154		eminder light	
			eat belt extenders	
R	Radar cruise control133	Se	eat belt pretensioners	35
	Radiator278		heaters	
	Radio 182	Seat	position memory	31
	RDS (Radio data system)183		ventilators	
	Rear sunshade233	Seatii	ng capacity	160
	Rear turn signal lights	Seats		
	Replacing light bulbs319	С	hild seats/child restraint	t
	Wattage	9	system installation	80
	Rear view mirror		leaning	
	Compass246		riving position memory.	
	Rear window defogger178		ont passenger seat pos	
	Replacing		memory	
	Electronic key battery302		ead restraint	
	Fuses304	Pr	operly sitting in the seat	t59
	Light bulbs319		eat adjustment	
	Reporting safety defects for	Se	eat adjustment precautio	ons27
	U.S. owners414	Se	eat heaters	228, 230
		Ve	entilated seats	230
S	Scuff lighting209	Servi	ce reminder indicators	115
_	Seat belts	Shift I	ever	
		Αι	utomatic transmission	101
	Adjusting the seat belt35 Automatic Locking Retractor	If t	the shift lever cannot be	
	(ALR)36	9	shifted from P	367
	(ALK)30	М	anual transmission	105

Shift lever lighting	209
Shift lock system	367
Shopping bag hooks	238
Side airbags	61
Side marker lights	
Switch	122
Side mirror	
Adjusting and folding	43
Driving position memory	28
Smart access system with	
push-button start	
Entry function	4
Starting the engine	98
Spare tire	
Inflation pressure	293
Spare tire	358
Spark plug	385
Specifications	380
Speedometer	
Speed indicator	109
Speedometer	109
Steering wheel	
Audio switches	207
Driving position memory	28
Manual adjustment	40
Power adjustment	41
Storage feature	213
Stuck	
lf your vehicle becomes stuck	377
Sun visors	219
Sunshade	
Rear	233
Roof	49
Switch	
ECT switch	102
Engine switch	98
ETCS switch	105

Fog light switch	
Light switches	122
Power door lock sv	vitch19
Power window swit	ch45
Satellite switches	222
Transmission shift s	witches103
Window lock switc	h45
Wipers and washer	switch126
Tachometer	
Tacho indicator	109
Tachometer	
Tail lights	
Switch	122
Theft deterrent system	
Alarm	
Engine immobilizer	
-	=
I nett prevention label:	s58
Theft prevention label: Tire inflation pressure	
·	
Tire inflation pressure	293
Tire inflation pressure Tire information	293
Tire inflation pressure Tire information Glossary	293 403 400
Tire inflation pressure Tire information Glossary	293 403 400 399
Tire inflation pressure Tire information Glossary Size Tire identification nu	293 403 400 399
Tire inflation pressure Tire information Glossary Size Tire identification no Uniform tire quality	
Tire inflation pressure Tire information Glossary Size Tire identification no Uniform tire quality Tires	
Tire inflation pressure Tire information Glossary Size Tire identification no Uniform tire quality Tires Chains	
Tire inflation pressure Tire information Glossary Size Tire identification no Uniform tire quality Tires Chains Checking If you have a flat tire	
Tire inflation pressure Tire information Glossary Size Tire identification not Uniform tire quality Tires Chains Checking	
Tire inflation pressure Tire information Glossary Size Tire identification not Uniform tire quality Tires Chains Checking If you have a flat tire Inflation pressure	
Tire inflation pressure Tire information Glossary Size Tire identification not Uniform tire quality Tires Chains Checking If you have a flat tire Inflation pressure see Inflation pressure see	
Tire inflation pressure Tire information Glossary Size Tire identification no Uniform tire quality Tires Chains Checking If you have a flat tire Inflation pressure see	
Tire inflation pressure Tire information Glossary Size Tire identification not Uniform tire quality Tires Chains Checking If you have a flat tire Inflation pressure see Information	
Tire inflation pressure Tire information Glossary Size Tire identification not Uniform tire quality Tires Chains Checking If you have a flat tire Inflation pressure Inflation pressure see Information Replacing Rotating tires	

otal load capacity	160	W Warning buzzers
owing		Brake system339
Dinghy towing		Open door341
Emergency towing		Seat belt reminder340
Trailer towing		Warning lights
C (Traction control)		Anti-lock brake system (ABS) 340
ction control (TRAC)		Brake assist system340
ınsmission shift switches		Brake system339
o meter	109	Charging system340
unk		Electric power steering
Extending a space	235	warning light340
Opener	23	Electronic engine control
unk light		system340
Trunk light	24	Low fuel level341
Wattage	394	Low tire pressure warning
rn signal lights		light341
Replacing light bulbs	319	Master warning light341
Switch	107	Open door341
Wattage	394	Pre-collision system340
		Pretensioners
nity lights		Seat belt reminder light341
Vanity lights	220	SRS airbags340
Wattage		Warning messages
nity mirrors		AWD system345
IM (Vehicle dynamics		Dynamic radar
ntegrated management)	148	cruise control345, 349
hicle dynamics integrated		Engine oil level349
nanagement (VDIM)	148	Engine oil maintenance349
hicle identification number		Engine oil pressure344
hicle stability control (VSC		Hill-start assist control348
entilators	•	Hood349
SC (Vehicle stability contro		Lexus parking assist
, , ,	, -	sensor345, 349
		Moon roof349
		Open door349
		Parking brake 340

Alphabetical index

Smart access system with	
push-button start	355
Steering lock	345
Tire inflation pressure	
warning system345	5, 349
Traction control (TRC)	
Trunk	349
Vehicle stability control	
(VSC)	348
Washer fluid	349
Washer	
Checking	282
Preparing and checking	
before winter	161
Switch	126
Washing and waxing	252
Weight	
Cargo capacity	157
Load limits	160
Weight	380
Wheels	297
Window glasses	45
Window lock switch	45
Windows	
Power windows	45
Rear window defogger	178
Washer	
Windshield wipers	126
Wireless remote control	
Replacing the battery	302
WMA disc	